

2 POST Corner Unit Parts List

1. 2 x Posts
2. Shelving Tiers
- 2 x Plastic Wedges per shelf
- 2 x Stainless Steel Shelf Clips per shelf

Weight Capacity
150kg
Per Tier
(2 Posts + 2 Clips)

STARTER BAY
CNR ADD-ON BAY

3 POST Corner Unit Parts List

1. 3 x Posts
2. Shelving Tiers
- 3 x Plastic Wedges per shelf
- 1 x Stainless Steel Shelf Clips per shelf

Weight Capacity
200kg
Per Tier
(3 Posts + 1 Clip)

STARTER BAY
CNR ADD-ON BAY

** It is recommended to remove Real Tuff 'Drop-On' Shelf (plastic) inserts before assembling, then replace after shelving is positioned*

1

2 Clips per Shelf + 2 Posts

+ Wedges

Approx. 10 to 20mm
Space out

Lift plastic shelf's off the bottom tier of the **Starter Bay** and Attach **two (2) Shelf Clips** onto front rail member of Shelving frame.

1

1 Clip per Shelf + 3 Posts

Space out

Lift plastic shelf's off the bottom tier of the **Starter Bay** and Attach **one (1) Shelf Clip** onto front rail member of Shelving frame.

2

Align the **2-POST** Add-on Bay with Starter Bay, and Lower open end of Tier onto clips so that both shelves are level.

Check that the tier has been correctly located onto each shelf clip

2

Align the **3-POST** Add-on Bay with Starter Bay, and Lower open end of Tier onto clip so that both shelves are level.

3

a. Clip 2 Wedges to both posts
b. Attach 2 Shelf Clips onto the Starter Bay
c. Lower next Shelving frame into position

D. Tap shelf down to fit firmly and securely onto each wedge and clip, using a light to medium force.

3

a. Clip 3 Wedges to each post
b. Attach 1 Shelf Clip onto the Starter Bay
c. Lower next Shelving frame into position

4

Cnr Add-On Weight Capacity
150kg
Per Tier
(evenly distributed)

e. Repeat step 3 to install remaining Shelving frames.
f. Replace Real Tuff Shelves back on each Shelving Tier
g. Level shelving by adjusting Bullet Feet using a spanner

F. 'Drop-On' + Slide each Real Tuff (plastic) Shelf, one at a time, to lock and engage together.

4

Cnr Add-On Weight Capacity
200kg
Per Tier
(evenly distributed)

e. Repeat step 3 to install remaining Shelving frames.
f. Replace Real Tuff Shelves back on each Shelving Tier
g. Level shelving by adjusting Bullet Feet using a spanner